

**HAIR TRIMMER VT-2550 B**

The trimmer is intended for cutting, trimming and adjusting hair. Attachments of different size are supplied with the unit for easy hair and body care. The unit is both cord-operated and battery-powered.

**DESCRIPTION**

1. Attachment lock button
2. Body
3. Charging indicator
4. Power switch
5. AC adapter slot
6. Storage base
7. Cleaning brush
8. Comb
9. Lubricating oil
10. AC adapter

11. Wide trimmer 40 mm
12. Telescopic attachment for trimmer 40 mm
13. Wide trimmer 30 mm
14. Telescopic attachment for trimmer 30 mm
15. Detail trimmer

**SAFETY MEASURES**

Before using the electric unit, read this instruction carefully and keep it for further reference. Use the unit according to its intended purpose only, as it is stated in this user manual.

- Misusing the unit can lead to its breakage and cause harm to the user or damage to his/her property.
- Before the first connecting the unit to the mains for battery charging, make sure that your home mains voltage corresponds to net adapter operating voltage.
- Use only the attachments and the adapter supplied.
- Do not immerse the unit, the adapter and adapter cord into water or other liquids; do not use the hair clipper while taking a bath or a shower.
- Do not use the unit in places with high temperature and relative humidity more than 80%.
- Charge the battery at the temperature from +5°C to +35°C.
- Use only the attachment combs supplied.
- Do not immerse the unit, the adapter and adapter cord into water or other liquids; do not use the hair clipper while taking a bath or a shower.
- Do not keep the unit near a bath, filled with water, or a sink. Do not immerse the unit into water or other liquids; do not wash the hair clipper under running water.
- Always keep the trimmer blades clean and lubricated.
- After each using clean the attachments with the brush supplied to remove the cut-off hair.
- Never leave the operating unit unattended.
- Switch the hair clipper off during intervals in operation or when you are not using it.
- The adapter cord should not:
  - touch hot objects and surfaces,
  - be immersed into water,
  - run over sharp edges,
  - be used as a handle for carrying the unit.
- Do not allow children to use the units as a toy.
- This unit is not intended for usage by children or disabled persons unless they are given all the necessary and understandable instructions by a person who is responsible for their safety on safety measures and information about danger that can be caused by improper usage of the unit.
- For children safety reasons do not leave polyethylene bags, used as a packaging, unattended.
- **Attention!** Do not allow children to play with polyethylene bags or packaging film.
- **Danger of suffocation!** Do not attempt to repair the unit. Do not disassemble the unit by yourself, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center at the contact addresses given in the warranty certificate and on the website [www.vitek.ru](http://www.vitek.ru)
- Do not use the unit in the original packaging only.
- Keep the unit in a dry cool place out of reach of children and disabled persons.

**Step 4 – cutting the top of the head**  
Using the telescopic attachment (14) in the position 9 or 11, cut the hair from the top of the head towards the crown against the hair growth direction.

- You can cut hair both against and along the hair growth direction, but keep in mind that their cutting against the growth direction will be shorter than the one along it.
- Set the telescopic attachment (12 or 14) to the position 3 and 6 for very short haircut. To leave longer hair, use the positions 7, 9 or 11 of the telescopic attachments (12 or 14).
- To leave longer hair, take hair locks between your fingers and cut hair using the hair clipper.
- You can use the comb (8): lift the hair locks and cut them with the hair clipper above the comb.
- Always start cutting from the head back.
- Set the hair with the comb (8) to reveal uneven locks.
- Use the scissors to trim hair.

**Step 5 – the final part**  
In the final stage of hair cutting remove the telescopic attachment from the unit, turn the blades of the hair clipper towards the hair and trim hair on the temples and neck carefully. Do not press the hair clipper strongly, there is danger of injuries or cuts when open blades come in contact with skin.

**Cone – shaped haircut**  
Set the necessary telescopic attachment and start cutting from the head back towards the crown. Cut hair against hair growth from the head front to the crown and on the head sides. To get a flat top haircut, use the comb (8): lift the locks and cut them along the comb. Set the hair with the comb (8) to reveal uneven locks.

**Cutting beard and mustaches**  
Use the trimmers (11, 13) with telescopic attachments (12, 14) for beard trimming, you can also use the detail trimmer (15).

- Install the trimmer (11 or 13) on the hair clipper and install the corresponding telescopic attachment (12 or 14) on the trimmer.
- Until you learn your hair clipper better, set the attachment combs to the positions «9» or «11», depending on the attachment; then you can reduce the haircut length gradually by adjusting the telescopic attachments.
- To cut the beard symmetrically start cutting from the ear to the chin on the one side of the face, and then repeat the beard cutting on the other side.
- When cutting mustaches, first comb them and then start cutting from the middle to the corners of the lips.

**Note:** Always cut off a little amount of hair at a time; if necessary you can always return to the cut area again for additional cutting.

In the final stage of beard cutting remove the telescopic attachment from the unit, turn the blades of the unit towards yourself and, pressing the hair clipper slightly, define the desired shape of the beard.

Do not press the hair clipper strongly, there is danger of injuries or cuts when open blades come in contact with skin  
When cutting hair on the cheeks, move the trimmer downwards and upwards on the neck.

After cutting of beard and mustaches, maintain their shape.

**CLEANING AND CARE**  
Switch the hair clipper off after use.

- Remove all the used attachments from the hair clipper and clean them inside and outside from hair, using the cleaning brush (7).
- You can wash the attachments under a water jet, then wipe them and dry thoroughly.
- Never use solvents or abrasives to clean the unit body and attachments.
- Never immerse the hair clipper, the adapter and the adapter cord into water or other liquids.

**Lubricating the trimmer blades (11, 13, 15)**  
Regularly lubricate the blades using the oil (9) supplied with the unit.

- Apply one or two drops of lubricating oil (9) on the teeth of the trimmer blades and the supporting part of the upper blade.
- Install the trimmer on the hair clipper body and switch the hair clipper on, make sure that the blades are moving smoothly.
- Switch the unit off, clean the excess oil with a dry cloth.

**Attention!** Use only the oil supplied with the unit.  
DO NOT use vegetable oil, fat and mixture of oil and solvents for lubrication. Solvents will evaporate, leaving thick grease that may slow down the blades motion.

**STORAGE**  
Keep the hair clipper and lubricate the blades of the trimmers (11, 13, 15) with lubricating oil (9) before taking the unit away for storage.

**RECYCLING**  
For environment protection do not discard the unit with usual household waste after its service life expiration; apply to specialized centers for further recycling. The waste generated during the disposal of the unit are subject to mandatory collection and consequent disposal in the prescribed manner.

**DELIVERY SET**  
1. Hair clipper – 1 pc.  
2. Wide trimmer 40 mm – 1 pc.  
3. Telescopic attachment for trimmer 40 mm – 1 pc.  
4. Wide trimmer 30 mm – 1 pc.  
5. Telescopic attachment for trimmer 30 mm – 1 pc.  
6. Detail trimmer – 1 pc.  
7. Comb – 1 pc.  
8. Lubricating oil – 1 pc.  
9. Cleaning brush – 1 pc.  
10. Storage base – 1 pc.  
11. Instruction manual – 1 pc.

**TECHNICAL SPECIFICATIONS**  
**Hair trimmer**  
Power consumption: 2.5 W  
Built-in rechargeable batteries: 2x1.2V 600mA Ni-MH  
Charging time: 8 hours  
Operation time: 35 min.  
**Power adapter:**  
Input voltage: 100-240V ~ 50/60Hz 0.06A  
Output voltage: 3 V === 800 mA  
Power consumption: 7 W

**ENGLISH**

**Reminder**  
- Always cut off a little amount of hair at a time - if necessary you can always return to the cut area again for additional cutting.  
- The best haircut results are reached on dry hair, not wet.  
- Set the hair with the comb (8) to reveal uneven locks.  
- It is better to leave longer hair after cutting for the first time.  
- After learning the unit better, you will be able to arrange your hair in any style you need.

**Step one**  
Install the telescopic attachment (12 or 14) to the position 3 or 6. Switch the hair clipper on using the button (4). Hold the unit with the blades pointed upwards. Start the haircutting from the beginning of the hair growth. Slowly move the clipper upwards. This way cut the head back area at neck bottom and near the ears.

**Step two**  
Switch the hair clipper off pressing the button (4), then, depending on the used telescopic attachment (12 or 14), set the attachment to the position 9 or 11, switch the hair clipper on and continue cutting hair near the top of the head.

**Step 3 – cutting temples**  
Switch the hair clipper off, then, depending on the used telescopic attachment (12 or 14), set the attachment to the position 3 or 6 and cut hair on the temples. Then, depending on the used telescopic attachment (12 or 14), set the attachment to the position 9 or 11, switch the hair clipper on and continue cutting hair towards the top of the head.

**Step 4 – cutting the top of the head**  
Using the telescopic attachment (14) in the position 9 or 11, cut the hair from the top of the head towards the crown against the hair growth direction.

- You can cut hair both against and along the hair growth direction, but keep in mind that their cutting against the growth direction will be shorter than the one along it.
- Set the telescopic attachment (12 or 14) to the position 3 and 6 for very short haircut. To leave longer hair, use the positions 7, 9 or 11 of the telescopic attachments (12 or 14).
- To leave longer hair, take hair locks between your fingers and cut hair using the hair clipper.
- You can use the comb (8): lift the hair locks and cut them with the hair clipper above the comb.
- Always start cutting from the head back.
- Set the hair with the comb (8) to reveal uneven locks.
- Use the scissors to trim hair.

**Step 5 – the final part**  
In the final stage of hair cutting remove the telescopic attachment from the unit, turn the blades of the hair clipper towards the hair and trim hair on the temples and neck carefully. Do not press the hair clipper strongly, there is danger of injuries or cuts when open blades come in contact with skin.

**Cone – shaped haircut**  
Set the necessary telescopic attachment and start cutting from the head back towards the crown. Cut hair against hair growth from the head front to the crown and on the head sides. To get a flat top haircut, use the comb (8): lift the locks and cut them along the comb. Set the hair with the comb (8) to reveal uneven locks.

**Cutting beard and mustaches**  
Use the trimmers (11, 13) with telescopic attachments (12, 14) for beard trimming, you can also use the detail trimmer (15).

- Install the trimmer (11 or 13) on the hair clipper and install the corresponding telescopic attachment (12 or 14) on the trimmer.
- Until you learn your hair clipper better, set the attachment combs to the positions «9» or «11», depending on the attachment; then you can reduce the haircut length gradually by adjusting the telescopic attachments.
- To cut the beard symmetrically start cutting from the ear to the chin on the one side of the face, and then repeat the beard cutting on the other side.
- When cutting mustaches, first comb them and then start cutting from the middle to the corners of the lips.

**Note:** Always cut off a little amount of hair at a time; if necessary you can always return to the cut area again for additional cutting.

In the final stage of beard cutting remove the telescopic attachment from the unit, turn the blades of the unit towards yourself and, pressing the hair clipper slightly, define the desired shape of the beard.

Do not press the hair clipper strongly, there is danger of injuries or cuts when open blades come in contact with skin  
When cutting hair on the cheeks, move the trimmer downwards and upwards on the neck.

After cutting of beard and mustaches, maintain their shape.

**CLEANING AND CARE**  
Switch the hair clipper off after use.

- Remove all the used attachments from the hair clipper and clean them inside and outside from hair, using the cleaning brush (7).
- You can wash the attachments under a water jet, then wipe them and dry thoroughly.
- Never use solvents or abrasives to clean the unit body and attachments.
- Never immerse the hair clipper, the adapter and the adapter cord into water or other liquids.

**Lubricating the trimmer blades (11, 13, 15)**  
Regularly lubricate the blades using the oil (9) supplied with the unit.

- Apply one or two drops of lubricating oil (9) on the teeth of the trimmer blades and the supporting part of the upper blade.
- Install the trimmer on the hair clipper body and switch the hair clipper on, make sure that the blades are moving smoothly.
- Switch the unit off, clean the excess oil with a dry cloth.

**Attention!** Use only the oil supplied with the unit.  
DO NOT use vegetable oil, fat and mixture of oil and solvents for lubrication. Solvents will evaporate, leaving thick grease that may slow down the blades motion.

**STORAGE**  
Keep the hair clipper and lubricate the blades of the trimmers (11, 13, 15) with lubricating oil (9) before taking the unit away for storage.


**RECYCLING**  
For environment protection do not discard the unit with usual household waste after its service life expiration; apply to specialized centers for further recycling. The waste generated during the disposal of the unit are subject to mandatory collection and consequent disposal in the prescribed manner.

**DELIVERY SET**  
1. Hair clipper – 1 pc.  
2. Wide trimmer 40 mm – 1 pc.  
3. Telescopic attachment for trimmer 40 mm – 1 pc.  
4. Wide trimmer 30 mm – 1 pc.  
5. Telescopic attachment for trimmer 30 mm – 1 pc.  
6. Detail trimmer – 1 pc.  
7. Comb – 1 pc.  
8. Lubricating oil – 1 pc.  
9. Cleaning brush – 1 pc.  
10. Storage base – 1 pc.  
11. Instruction manual – 1 pc.

**TECHNICAL SPECIFICATIONS**  
**Hair trimmer**  
Power consumption: 2.5 W  
Built-in rechargeable batteries: 2x1.2V 600mA Ni-MH  
Charging time: 8 hours  
Operation time: 35 min.  
**Power adapter:**  
Input voltage: 100-240V ~ 50/60Hz 0.06A  
Output voltage: 3 V === 800 mA  
Power consumption: 7 W

The manufacturer preserves the right to change the specifications of the unit without a preliminary notification.

**Unit operating life is 3 years**  
**Guarantee**  
Details regarding guarantee conditions can be obtained from the dealer from whom the appliance was purchased. The bill of sale or receipt must be produced when making any claim under the terms of this guarantee.



**РИММЕР ДЛЯ ВОЛОС VT-2550 B**

Триммер предназначен для стрижки, выравнивания и корректировки волос. В комплект поставки входят насадки разного размера, которые облегчают уход за волосами и различными частями тела. Устройство работает от сети и от встроенной аккумуляторной батареи.

**ОПИСАНИЕ**

1. Клавиша фиксатора насадок
2. Корпус
3. Индикатор зарядки
4. Выключатель питания
5. Гнездо подключения разъёма провода сетевого адаптера
6. Подставка для хранения
7. Щётка для чистки
8. Расчёска
9. Масло для смазки
10. Сетевой адаптер

11. Широкий триммер 40 мм
12. Телескопическая насадка для триммера 40 мм
13. Широкий триммер 30 мм
14. Телескопическая насадка для триммера 30 мм
15. Детальный триммер

**МЕРЫ БЕЗОПАСНОСТИ**

Перед началом эксплуатации электроприбора внимательно прочитайте настоящую инструкцию по эксплуатации и сохраните её для использования в качестве справочного материала. Используйте устройство только по его прямому назначению, как изложено в данной инструкции.

- Неправильное обращение с прибором может привести к его поломке, причинно связанной с использованием его имущества.
- Перед первым подключением устройства к сети для зарядки аккумуляторной батареи убедитесь в том, что напряжение электрической сети соответствует рабочему напряжению сетевого адаптера.
- Используйте только те насадки и сетевой адаптер, которые входят в комплект поставки.
- Запрещается использовать машинку с повреждёнными насадками или лезвиями.
- Не используйте устройство в местах с повышенной температурой и относительной влажностью более 80%.
- Производите зарядку аккумуляторной батареи при температуре от +5°С до +35°С.
- Используйте только те насадки-расчески, которые входят в комплект поставки.
- Не погружайте устройство, сетевой адаптер и шнур сетевого адаптера в воду и другие жидкости, не используйте машинку во время принятия ванны или душа.
- Не храните прибор рядом с ванной, наполненной водой, или раковины.
- Не погружайте прибор в воду или в другие жидкости, не промывайте машинку под струей воды.
- Всегда следите за чистой лезвий триммером и наличием на них смазочного масла.
- После каждого использования очищайте насадки от срезанных волос при помощи щётки.
- Никогда не оставляйте работающее устройство без присмотра.
- Выключайте машинку в перерывах в работе, а также в тех случаях, когда вы ею не пользуетесь.
- Шнур сетевого адаптера не должен:
  - соприкасаться с горячими предметами и поверхностями,
  - погружаться в воду,
  - протягиваться через острые кромок,
  - использоваться в качестве ручки для переноски устройства.
- Не разрешайте детям использовать устройства в качестве игрушек.
- Данное устройство не предназначено для использования детьми и людьми с ограниченными возможностями, если только только лицом, отвечающим за их безопасность, им не даны соответствующие и полные инструкции о безопасном использовании устройства и тех опасностях, которые могут возникнуть при его неправильном использовании.
- Из соображений безопасности детей не оставляйте полиэтиленовые пакеты, использованные в качестве упаковок, без надзора.
- **Внимание!** Не разрешайте детям играть с полиэтиленовыми пакетами или упаковочной плёнкой. Опасность удушья!
- Запрещается самостоятельно ремонтировать прибор. Не разбирайте прибор самостоятельно, при возникновении любых неисправностей, а также попадания устройства выключите прибор из электрической розетки и обратитесь в любой авторизованный (уполномоченный) сервисный центр по контактным адресам, указанным в гарантийном талоне и на сайте [www.vitek.ru](http://www.vitek.ru)
- Во избежание повреждений персонажите устройство только в заводской упаковке.
- Храните устройство в сухом прохладном месте, недоступном для детей и людей с ограниченными возможностями.

**Устройство предназначено только для бытового использования**  
Используйте устройство только по его прямому назначению, как изложено в данной инструкции.

- Перед первым подключением устройства к сети для зарядки аккумуляторной батареи убедитесь в том, что напряжение электрической сети соответствует рабочему напряжению сетевого адаптера.
- Используйте только те насадки и сетевой адаптер, которые входят в комплект поставки.
- Запрещается использовать машинку с повреждёнными насадками или лезвиями.
- Не используйте устройство в местах с повышенной температурой и относительной влажностью более 80%.
- Производите зарядку аккумуляторной батареи при температуре от +5°С до +35°С.
- Используйте только те насадки-расчески, которые входят в комплект поставки.
- Не погружайте устройство, сетевой адаптер и шнур сетевого адаптера в воду и другие жидкости, не используйте машинку во время принятия ванны или душа.
- Не храните прибор рядом с ванной, наполненной водой, или раковины.
- Не погружайте прибор в воду или в другие жидкости, не промывайте машинку под струей воды.
- Всегда следите за чистой лезвий триммером и наличием на них смазочного масла.
- После каждого использования очищайте насадки от срезанных волос при помощи щётки.
- Никогда не оставляйте работающее устройство без присмотра.
- Выключайте машинку в перерывах в работе, а также в тех случаях, когда вы ею не пользуетесь.
- Шнур сетевого адаптера не должен:
  - соприкасаться с горячими предметами и поверхностями,
  - погружаться в воду,
  - протягиваться через острые кромок,
  - использоваться в качестве ручки для переноски устройства.
- Не разрешайте детям использовать устройства в качестве игрушек.
- Данное устройство не предназначено для использования детьми и людьми с ограниченными возможностями, если только только лицом, отвечающим за их безопасность, им не даны соответствующие и полные инструкции о безопасном использовании устройства и тех опасностях, которые могут возникнуть при его неправильном использовании.
- Из соображений безопасности детей не оставляйте полиэтиленовые пакеты, использованные в качестве упаковок, без надзора.
- **Внимание!** Не разрешайте детям играть с полиэтиленовыми пакетами или упаковочной плёнкой. Опасность удушья!
- Запрещается самостоятельно ремонтировать прибор. Не разбирайте прибор самостоятельно, при возникновении любых неисправностей, а также попадания устройства выключите прибор из электрической розетки и обратитесь в любой авторизованный (уполномоченный) сервисный центр по контактным адресам, указанным в гарантийном талоне и на сайте [www.vitek.ru](http://www.vitek.ru)
- Во избежание повреждений персонажите устройство только в заводской упаковке.
- Храните устройство в сухом прохладном месте, недоступном для детей и людей с ограниченными возможностями.

**ИСПОЛЬЗОВАНИЕ МАШИНКИ ДЛЯ СТРИЖКИ**  
После транспортировки или хранения устройства при пониженной температуре необходимо выдержать его при комнатной температуре не менее двух часов.

**Зарядка аккумуляторной батареи**  
При полном заряде аккумуляторной батареи время непрерывной работы машинки составляет около 35 минут.

- Вставьте разъём сетевого адаптера (10) в гнездо (5), расположенное на корпусе машинки (2), вставьте сетевой адаптер в электрическую розетку, при этом индикатор зарядки (3) загорится синим цветом.
- Первый цикл зарядки составляет 10-12 часов, повторная зарядка батареи занимает около 8 часов.
- Когда зарядка аккумуляторной батареи будет завершена, индикатор (3) погаснет. Извлеките сетевой адаптер (10) из электрической розетки и извлеките разъём провода адаптера из гнезда (5).

**Примечание:**  
• Производите повторную зарядку аккумуляторной батареи только после её полной разрядки.  
• Производите зарядку аккумуляторов при температуре от +5°С до +35°С.  
• Не оставляйте включённое в сеть устройство без присмотра.  
• Если вы не пользовались устройством продолжительное время (более 3 месяцев), перед использованием машинки производите полную зарядку аккумуляторной батареи (10-12 часов).  
• Устройство можно использовать и для работы от электрической сети.

**Насадки**  
- Храните насадки на подставке (6).  
- Перед установкой и заменой насадки выключите устройство, нажав на кнопку (4), при работе от сетевого адаптера извлеките его из электрической розетки.  
- Снимите клавишу фиксатора (1) от насадки и, удерживая клавишу (1), снимите насадку с корпуса (2).  
- Для установки требуемой насадки вставьте фиксатор на нижней части насадки в паз на задней стенке корпуса (2), а затем, отодвинув клавишу (1) от насадки, вставьте насадку до упора и отпустите клавишу фиксатора (1).

**Установка телескопических насадок**  
- **Телескопическая насадка для триммера 40 мм**  
Наденьте телескопическую насадку (12) на триммер (11), при этом нижняя защёлка насадки (12) должна зафиксироваться на триммере (11). Регулировка длины срезаемых волос производится перемещением расчески относительно триммера (11) в пределах 3, 5, 7, 9, 11 мм.  
- **Телескопическая насадка для триммера 30 мм**  
Наденьте насадку (14) на триммер (13) со стороны лезвий по направлению вниз до упора. Регулировка длины срезаемых волос производится перемещением насадки относительно триммера (13) в пределах 3, 5, 7, 9 мм. Снятие насадки (14) производится перемещением её по направлению вверх относительно триммера (13).

**Смазочное масло**  
- Для поддержания машинки в рабочем состоянии необходимо смазывать лезвия триммеров (11, 13, 15) после каждого использования машинки.  
- Для смазки лезвий используйте только то смазочное масло (9), которое входит в комплект поставки.

**Работа с машинкой для стрижки**  
- Перед тем как работать от аккумуляторной батареи, произведите полную зарядку батареи.  
• Установите необходимую насадку.  
**Примечание:** Для работы от электрической сети подсовините разъём провода сетевого адаптера (10) к гнезду (5) на корпусе (2) и вставьте сетевой адаптер (10) в электрическую розетку. Включите устройство, нажав кнопку (4).  
Закрепите работу с устройством, выключите его, нажав кнопку (4).

**Примечание:**  
- Каждый раз при необходимости сделать перерыв в работе выключайте машинку.  
- При работе от электрической сети во время замены насадок выключайте машинку и вынимайте сетевой адаптер из электрической розетки.

**Стрижка волос**  
Для создания причёски используйте триммеры (11, 13) с соответствующими телескопическими насадками (12, 14).  
Для художественной стрижки на коротких волосах можно использовать детальный триммер (15).  
• Во время стрижки волосы должны быть чистыми и сухими.  
• Установите необходимую насадку.  
• Перед началом стрижки включите машинку, нажав кнопку (4), и убедитесь в том, что машинка работает без сбоя, а ход лезвий – плавный. При выборе на лезвиях небольшое масла его следует удалить при помощи сухой ткани.  
• Выключите устройство, установив выключатель (4) в положение «0», затем установите на триммер (11 или 13) соответствующую телескопическую насадку (12 или 14).  
• Посадите человека таким образом, чтобы его голова была примерно на уровне ваших глаз, прикройте плечи полотенцем, расчешите волосы при помощи расчески (8).  
• Выключите устройство, нажав кнопку (4).

**РУССКИЙ**

**Напоминание**  
- Срезайте небольшое количество волос за один проход, в случае необходимости всегда можно вернуться к уже подстриженному участку для дополнительной стрижки.  
- Расчесывайте волосы расческой (8) для выявления неровных прядей.  
- Для первого раза после стрижки лучше оставить более длинные волосы.  
- По мере освоения устройства, вы сможете самостоятельно моделировать необходимые причёски.

**Шаг первый**  
Установите телескопическую насадку (12 или 14) в положение 3 или 6. Включите машинку кнопкой (4). Держите машинку таким образом, чтобы лезвия были направлены вверх. Начинать стрижку с начала роста волос. Медленно перемещайте машинку по направлению вверх. Подстригите все волосы снизу задней части головы и около ушей.

**Шаг второй**  
Отключите машинку, нажав кнопку (4), в зависимости от используемой телескопической насадки (12 или 14) установите насадку в положение 9 или 11, включите машинку и продолжайте стричь волосы ближе к макушке.

**Шаг 3 – стрижка в области висков**  
Отключите машинку, в зависимости от используемой телескопической насадки (12 или 14) установите насадку в положение 3 или 6 и подстригите волосы на висках. Затем, в зависимости от используемой телескопической насадки (12 или 14) установите насадку в положение 9 или 11 и продолжайте стрижку по направлению к макушке.

**Шаг 4 – стрижка в области темени**  
Используйте телескопическую насадку (14) в положении 9 или 11, стригите волосы по направлению от макушки к темени, против направления роста волос.

- Волосы можно стричь против направления роста и по направлению роста, но имейте в виду, что стрижка по направлению к макушке и с боков, будет короче волос, подстриженных по направлению роста.
- Устанавливайте телескопическую насадку (12 или 14) в положение 3 и 6 для очень короткой стрижки. Чтобы волосы не росли слишком быстро, используйте телескопические насадок (12 или 14) 7, 9 или 11.
- Чтобы оставить более длинные волосы, зажимайте пряди волос между пальцами и состригайте их коротко расческой (8) для выявления неровных прядей.
- Всегда начинайте стрижку с задней части головы.
- Расчесывайте волосы расческой (8) для выявления неровных прядей.
- Используйте ножницы для подравнивания волос.

**Шаг 5 – заключительная часть**  
Заключительная часть моделирования причёски снимите телескопическую насадку, разверните машинку лезвиями в сторону волос и аккуратно подравняйте волосы на висках и на шее. Не надавливайте сильно на машинку, при контакте струей воды.

**Конусообразная стрижка**  
Установите необходимую телескопическую насадку и начните стрижку с задней части головы по направлению к макушке. Подстригите волосы против направления их роста с помощью расчески (8) для выявления неровных прядей. Для получения стрижки с плоской макушкой используйте расческу (8): приподнимайте и состригайте пряди волос по расческе. Расчесывайте волосы расческой (8) для выявления неровных прядей.

**Стрижка бороды и усов**  
Для моделирования бороды используйте триммеры (11, 13) и телескопическими насадками (12, 14), а также можно использовать детальный триммер (15).  
- Установите на машинку для стрижки триммер (11 или 13), а на триммер установите соответствующую телескопическую насадку (12 или 14).  
- После вы не освоили машинку для стрижки, лучше устанавливать насадки-расчески в положение «9» или «11», в зависимости от насадки, и постепенно подравнивайте телескопические насадки в сторону уменьшения длины волос.

- Для того, чтобы подстричь бороду симметрично, начинайте стрижку по направлению от уха в сторону подбородка с одной стороны лица, а затем повторите стрижку бороды с другой стороны лица.  
- При стрижке усов сначала расчешите их, а затем начинайте подстригать их в направлении от середины к уголкам губ.

**Примечание:** Срезайте небольшое количество волос за один проход, в случае необходимости всегда можно вернуться к уже подстриженному участку для дополнительной стрижки.  
- На заключительной стадии стрижки бороды снимите телескопическую насадку, поверните устройство л





АУДИО-ВИДЕО И БЫТОВАЯ ТЕХНИКА

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

## УКРАЇНСЬКА

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

## КАЗАҚША

—

—

—

—

—

—

—

—

—

—

—

—

—

—